

Topeak Rear Rack Installation

Only for use on models that have an extended dropout that moves the attachment hole rearward 3".

Step 1. Attach rack strut to rear hole on dropout.



Step 2. Attach custom mounting bracket to the four holes at the front of the rack.



Step 3. Attach extension tubes to outside of custom mounting bracket with bolt. Attach bottom of tubes to threaded insert on seat stays using C clamp.



Step 4. Level rack and tighten all bolts.

Step 5. Enjoy!



Questions? Call 406/570-1927